


Index			Index		
No.	Part No.	Description	No.	Part No.	Description
1.	47-020953-004	Stop Collar	35.	47-021110-004	Spacer
2.	99-010108-004	Bearing	36.	47-021120-004	Mounting Plate
3.	47-021466-001	Bearing Block	37.	47-020947-003	Bearing Block
4.	11-051706-001	Hex Nut (12 mm)	38.	N.A.	Wood Shim (5 mm)
5.	11-052024-001	N.A. Flat Washer (13 mm)	39.	47-021318-003	Wood Shim (10 mm)
	47-861010-001	R.O. Flat Washer (13 mm) Pkg. of 20	40.	11-051745-001	Locknut (10 mm)
6.	11-051772-001	Lockwasher (12 mm)	41.	47-025045-009	R.H. Ball Cushion Board w/Facing (even lane)
7.	11-051564-009	Socket Hd. Cap Screw (12 mm x 60 mm)	42.	47-021872-003	Top Ball Cushion Board
8.	11-051012-001	Hex Hd. Cap Screw (10 mm x 70 mm)	43.	11-052618-001	Carriage Bolt (10 mm x 50 mm)
9.	11-052050-001	Flat Washer (10.5 mm)	44.	47-025044-009	L.H. Ball Cushion Board w/Facing (odd lane)
10.	11-051771-001	Lockwasher (10 mm)	45.	11-052603-001	Carriage Bolt (8 mm x 45 mm)
11.	11-051703-001	Hex Nut (10 mm)	46.	47-026102-009	AP Impact Strips (Qty. 2)
12.	47-020948-003	Transverse Bar		47-021010-003	Impact Strip (Black) (Qty. 1)
	47-024077-003	Transverse Bar (short pit)	47.	11-051055-001	Hex Hd. Cap Screw (8 mm x 60 mm)
13.	11-051058-001	Hex Hd. Cap Screw (10 mm x 55 mm)	48.	47-021195-002	Pulley Holder Complete
14.	47-021009-002	Pulley Holder	49.	11-051744-001	Locknut (8 mm)
15.	11-051786-001	Split Pin (2.5 mm x 25 mm)	50.	11-052018-001	Flat Washer (10.5 mm)
16.	11-051014-001	Hex Hd. Cap Screw (6 mm x 45 mm)	51.	47-022410-003	Pulley w/Bearing
17.	11-052012-001	Flat Washer (18 mm)	52.	47-021112-004	Bushing
18.	11-052048-001	Flat Washer (6.4 mm)	53.	11-051515-001	Socket Hd. Cap Screw (6 mm x 18 mm)
19.	11-051743-001	Locknut (6 mm)	54.	11-051702-001	Hex Nut (6 mm)
20.	N.A.	Long Brake Plate (for single feed distributors)	55.	47-021488-004	Long Spacer
21.	N.A.	Rubber Material (rear)	56.	N.A.	L.H. Ball Cushion Frame Assembly odd lane Complete
22.	47-022098-004	Hydraulic Protector Plate	57.	N.A.	R.H. Ball Cushion Frame Assembly even lane Complete
23.	11-051704-001	Hex Nut (8 mm)	58.	47-274281-009	Ball Cushion Repair Kit
24.	47-021489-004	Short Spacer	59.	47-024276-004	Rubber Head Screws
25.	11-051052-001	Hex Hd. Cap Screw (10 mm x 45 mm)	60.	47-023660-004	Cap
26.	N.A.	Short Brake Plate	61.	N.A.	Jam Nut (12 mm x 8 mm)
27.	N.A.	Rubber Material (forward)	62.	47-021119-004	Special Round Top Nut (12 mm)
28.	11-051879-001	N.A. Truss Hd. Machine Screw (6 mm x 20 mm)	63.	11-052015-001	Flat Washer (13 mm)
	47-861007-001	R.O. Truss Hd. Machine Screw (6 mm x 20 mm) Pkg. of 5	64.	N.A.	R.H. Cushion Flap (even lane)
29.	11-053578-000	Rubber Bumper - male (8 mm)	65.	N.A.	L.H. Cushion Flap (odd lane)
30.	47-025639-009	Ball Cushion Frame w/Bracket (for both R.H. and L.H. machines)	66.	99-020402-002	N.A. Ball Cushion Hydraulic - Complete (all GS Pinsetters)
31.	47-274888-009	Cushion Flap Kit Complete		99-026121-000	R.O. Ball Cushion Hydraulic Assembly
32.	N.A.	Ball Cushion Hydraulic Complete	67.	47-021108-004	Spacer (used in new and old Shock)
	99-020402-002	N.A. Cushion Flap Assembly	68.	11-055351-000	Sealing Ring (all GS Shocks)
	99-026121-000	R.O. Hydraulic Ball Cushion Assembly	69.	47-071602-004	Compression Spring
33.	N.A.	Hydraulic Mounting Plate	70.	47-025637-003	Bracket
34.	11-051013-001	Hex Hd. Cap Screw (10 mm x 90 mm)	71.	47-025638-004	Spacer

N.A. = No Longer Available
R.O. = Replacement Option

Ball Cushion Assembly



Ball Cushion Assembly